

Preference Settings

- Automatic loading of preferences from the DWG file.
(When opening a DWG file, the relevant preference file automatically loads up. It includes the latest modifications).
- Working unit.
- Drafting scale.
- Layer management:
 - › By specialty, by geographical location and by single-line or double-line drawing mode (very flexible).
 - › By type of graphic entity (network, materials...).
 - › Several types of layer combinations (time saving)
- Graphic variables for representation of:
 - › The appearance of ducts.
 - › Texts, dimensions, arrows, conduits intersections.
- A range of hatching styles to symbolise coverings (thermo isolation, flocking).

Computation variables

- Conversion of rectangular/circular sections, coefficient of roughness of materials.
- Flow units, pressure drops units.
- Sets the TP scales and handles switching between model space and paper space automatically.
(Can be switched on or off.)

Management of drawing backgrounds

- Colour of entities.
- Colour of layers.
- Resetting the Z coordinate.
- Option to isolate texts, hatches, dimensions...
- Text fonts handling.
- Option for renaming layers for intelligent sorting.
- Management of the unit system (Metrique/Imperial).
- Line thickness and TP scale management.
- ...

Drafting

- Point to point pipe routing in single-line or double-line mode according to the material specifications.
- Standard specifications for heating and air conditioning.
- Five specifications specially developed for steel, copper and PVC pipework.
- 19 pipework specifications available for filling according to your needs.
- Point to point single-line routing of a set of pipes (up to 6 pipes).

- Cross-sectional drawing and computation of the distance between the centres within the set of pipes.
- Automatic insertion of the list of conduits constituting a set of pipes.
- Detailed drawing of all the accessories according to their configuration.
- Insertion of water fittings in line.
- Insertion of water fittings onto drafted pipes.
- Library of standard components.
- Drawings of the different types of heaters (panel-type radiators, multiple elements radiators...).
- Symbolic or realistic representation of the heaters.
- Insertion of assigned tags (descriptive tags) to the heaters.

Quick Modification Tools

- Changing an object (turning an elbow into a slope, changing the ND of an already drawn duct, changing a topside connection into an underside connection...).
- Moving an object (when drawing a reduction the conduits adjust and adjacent elbows follow automatically...).
- Deleting an object (the conduit 'closes' automatically on deleting a valve or a connection...).



Other Features

- Show crossed networks in double-line or single-line (by hiding or 'cutting' with an offset of one duct in relation to another, with only 2 mouse clicks).
- Automatic rebuild of sectioned conduits.
- Manipulation of layers (freeze, transfer, lock, etc...).
- Dimensioning settings (unit, number of decimals, arrows, etc...).
- Simpler dimensioning operations than with ZWCAD.
- Automatic update of dimensions on changing the settings.
- Proportionality factor.
- Thickness management.
- Type of lines containing letters.

Texts

- Single-line or multi-line texts.
- Automatic update of the number of lines.
- 'Click to text' function: when clicking onto a network, some of the related technical data automatically pre-populate the text field (such as the air duct portion).
- Automatic insertion of prefixes and suffixes in the texts.
- Automatic section formatting according to the material specifications.
- Automatic insertion of leader lines, frames, arrows, points, etc.

- Automatic adjustment of the leader line and frame when the text is modified.
- Choice of the character font and of its size.
- Automatic scaling.

Arrows

- Automatic drawing and positioning of flow direction arrows.
- Automatic adjustment of arrow directions.

Quantities

- Definition of plan zones for the network and material bills creation.
- Immediate and automatic extraction of conduits quantities within the predefined zones.
- Immediate and automatic extraction of equipment quantities within the predefined zones.
- Material bills exportation to ZWCAD or EXCEL.
- Automatic insertion and management of assigned blocks.

Openings

- Drawing of openings in slabs or in walls using the conduits' drawing.
- Drawing of openings in slabs or in walls without using the conduits' drawing.

- Choose the shape of the openings.
- Automatic dimensioning of openings.
- Automatic location and tagging of markers.
- Update of an opening drawing on changing its assigned tag.
- Extraction of openings list and export to ZWCAD or EXCEL.

Page Layout

- Automatic drawing page layout with creation of presentations.
- Automatic insertion of formats and title blocks.
- Create detailed views.
- Calculate the scales and update the scale of views.
- Automatic insertion in the margin of the file name, of its path and of its associated XREF.

Computation

Sizing and Altimetry

- Computation of a duct section according to the airflow (or power and Delta T), in relation with speed constraints or pressure drops limitations.
- Computation of the coefficient of friction (j) of a duct section.
- Computation of a network size according to its representation.
- Computation of levels while routing on change of duct section.

